

Nuby
Electric Steam Steriliser & Dryer



For competitions & offers join us on




@nubyuk

Nuby
Nuby UK LLP
Unit 6, Bolton Court
Burford Way
Bolton Business Park
Newcastle upon Tyne
NE35 9PY
Freephone number:
0800 334 5844
enquiries@nuby-uk.com
www.nuby-uk.com
www.nuby.com
Made in China

Form NPIC/UK 9950
© 2017 Lev n' canb, Ltd.
One-Touch™, and Nuby™ are trademarks licensed to Lev n' canb, Ltd.
PRODUCT DESIGN TM & ©
Facebook® is a registered trademark of Facebook, Inc.

BPA FREE

Getting to know the parts of your
Nuby
 Electric Steam Steriliser & Dryer



1. Main Body
2. Base
3. Upper Tray
4. Lid
5. Lower Tray

ON/OFF switch is located on the base of the Electric Steam Steriliser & Dryer unit.

Troubleshooting

Problem	Possible Cause	Solution
Appliance will not start.	Unit is unplugged. Unit is not turned on. Insufficient water in heater plate area.	Make sure the plug is securely inserted into the socket. Press on switch to use. Add 90ml water to heater plate.
Dryer function will not start.	Insufficient water added to heater plate area. If insufficient water is used and evaporates before the end of the sterilisation cycle the appliance will shut off.	Allow unit to cool and add 90ml water to heater plate.
Scaling on heater plate.	Your unit may require descaling.	You should descale your unit every 4 weeks. See section regarding descaling your unit in this leaflet (page 9).

Operation

LED	Status
Indication	Unit is performing selected sterilisation option
Solid light	Unit is in standby mode
Flashing light	Unit has finished cycle
No light (no water on heater plate)	May indicate malfunction - please contact enquiries@nuby-uk.com
No light (water on heater plate)	

Limited Product Warranty

Nuby's Electric Steam Steriliser & Dryer includes a one-year limited warranty against defects from the date of purchase. In the event of a malfunction or defect during the in-warranty period, Nuby™, at its discretion, will replace or repair the product under warranty. Upon receipt of the product and the proof of purchase with a valid date of purchase, the defective part will be immediately repaired or replaced and returned to you free of charge. Please send defective unit, proof of purchase with valid date of purchase, and a description of the problem you have encountered to:

Nuby UK LLP
Unit 6, Bolton Court
Burford Way
Bolton Business Park
Newcastle upon Tyne
NE35 9PY
Attn: Electric Steam Steriliser & Dryer

Note: This warranty does not cover a defect that has been caused by negligence, accident or improper use of the product.

Questions: Call 0800 334 5844 (UK only), email enquiries@nuby-uk.com or visit www.nuby-uk.com

Print Above pages front and back. Side B should be printed on the BACK of the same page that Side A is printed on

Nuby Electric Steam Steriliser & Dryer

To Clean:
Clean unit and parts before initial use and after each subsequent use. Always unplug unit and ensure that it is cool before cleaning.
Sterilising unit: Wipe surface of unit as well as inside of the warming basin with a damp cloth or sponge using mild liquid soap. Wipe with clean water. Do not submerge unit.
Upper tray, lower tray and lid: Dishwasher safe (top rack) or wash with soapy water. Rinse with clean water. Allow to air dry. Do not use scouring pads, abrasives or solvents for cleaning; they may damage the appliance and its surfaces.

To Descal:
It is helpful to descale your steriliser every four weeks to ensure that it continues to work properly. To descale, mix 2 oz (60 ml) of white vinegar with 4 oz (100 ml) of cold water and pour into the sterilising basin. Allow liquid to stand in the unit until any deposits (limescale) have dissolved. Discard liquid and rinse with clean water. Any other servicing should be performed by an authorised service representative.

Electrical Rating: Input voltage: 220V - 240V
USA Safety Approval: C-UL-US
EU Safety Approval: CB, GS

Table of Contents

Electric Steam Steriliser & Dryer Parts Guide	1
Important Safety Information and Instructions	3-4
First Time Use	5
Instructions for all Cycles – Sterilise only / Sterilise & Quick Dry / Sterilise & Super Dry	6-8
Cleaning Instructions	9
Troubleshooting / Operation / Product Warranty	10

Please note: the unit will require descaling every 4 weeks, unless you live in a hard water area, in which case you will need to descale more frequently. Please see page 9 for details on how to descale and clean the unit.

IMPORTANT SAFETY INFORMATION

KEEP THIS INSTRUCTION BOOKLET FOR FUTURE REFERENCE AS IT INCLUDES IMPORTANT INFORMATION.

- MISUSE OF THE PRODUCT MAY RESULT IN THE RISK OF FIRE, ELECTRIC SHOCK AND/OR PERSONAL INJURY.
- THIS APPLIANCE IS INTENDED FOR HOUSEHOLD USE ONLY. DO NOT USE OUTDOORS.
- BEFORE PLUGGING IN THE STERILISER & DRYER FOR THE FIRST TIME ENSURE THAT THE VOLTAGE IS COMPATIBLE WITH YOUR ELECTRICITY SUPPLY.
- ENSURE WATER HAS BEEN ADDED TO THE UNIT BEFORE SWITCHING THE UNIT ON.
- DO NOT IMMERSIVE THE UNIT IN WATER.
- APPLIANCE CAN BE USED BY PERSONS WITH REDUCED PHYSICAL SENSORY OR MENTAL CAPABILITIES OR LACK OF EXPERIENCE AND KNOWLEDGE IF THEY HAVE BEEN GIVEN SUPERVISION OR INSTRUCTION CONCERNING USE OF THE APPLIANCE BY A PERSON RESPONSIBLE FOR THEIR SAFETY.
- CHILDREN SHOULD NOT PLAY WITH THE APPLIANCE.
- THE SURFACES ARE LIABLE TO GET HOT IN USE.
- DO NOT TOUCH HOT SURFACES, OPEN USING THE HANDLE ON TOP OF THE LID ONLY.
- THE HEATING ELEMENT SURFACE IS SUBJECT TO RESIDUAL HEAT AFTER USE.
- WHEN IN USE THE STERILISER CONTAINS HOT WATER AND STEAM. KEEP HANDS AWAY FROM STEAM VENTS AS IT CAN CAUSE BURNS AND SCALDS. USE IN A WELL VENTILATED AREA, NEVER OPEN LID WHEN IN USE.
- ALWAYS USE ON A FLAT HEAT RESISTANT SURFACE.
- DO NOT MOVE THE APPLIANCE WHEN IN USE.
- DO NOT LET THE CORD HANG OVER THE EDGE OF THE KITCHEN WORK BENCH. THE PRODUCT HAS BEEN FITTED WITH A CORD WIND WHICH ALLOWS YOU TO ADJUST THE LENGTH OF THE CORD. IT IS RECOMMENDED THAT THE CORD IS KEPT AS SHORT AS POSSIBLE.
- UNPLUG WHEN NOT IN USE AND BEFORE CLEANING. ALLOW TO COOL BEFORE PLACING OR REMOVING TRAYS AND BEFORE CLEANING.
- DO NOT MOVE APPLIANCE WHEN IT IS IN USE OR IF IT CONTAINS HOT WATER.

STERILISATION & QUICK DRY instructions:

REPEAT STEPS 1 TO 8 FROM STERILISATION ONLY INSTRUCTIONS

9. Select sterilisation & quick dry function by pressing the button twice. The buzzer will beep twice and the middle light will come on and flash. After 5 seconds, the cycle will start automatically if there are no further button presses. The warm up process takes approximately 3 minutes.

10. The sterilisation cycle will last approximately 5 minutes. Once this is complete, the unit will stop for 2 minutes then automatically switch to drying function. When finished, buzzer will beep three times and the middle light will switch off. The accessories will be ready to use.

11. Once you have removed the accessories and the main body from the base pour out any excess water and wipe dry.

PLEASE NOTE: EXCESS WATER SHOULD BE Poured OUT OF THE FRONT OF THE STEAM STERILISER AND DRYER TO PREVENT WATER ENTERING AIR VENTS.

You can press the button any time to stop the cycle.

STERILISATION & SUPER DRY instructions:

REPEAT STEPS 1 TO 8 FROM STERILISATION ONLY INSTRUCTIONS

9. Select sterilisation & super dry function by pressing the button three times. The buzzer will beep three times and the bottom light will come on and flash. After 5 seconds, the cycle will start automatically if there are no further button presses. The warm up process takes approximately 3 minutes.

10. The sterilisation cycle will last approximately 5 minutes. Once this is complete, the unit will stop for 2 minutes then automatically switch to drying function. When finished, buzzer will beep three times and the bottom light will switch off. The accessories will be ready to use.

11. Pour out any excess water and wipe dry.

PLEASE NOTE: EXCESS WATER SHOULD BE Poured OUT OF THE FRONT OF THE STEAM STERILISER AND DRYER TO PREVENT WATER ENTERING AIR VENTS.

You can press the button any time to stop the cycle.

Print Above pages front and back. Side B should be printed on the BACK of the same page that Side A is printed on

5. Add the teat and screw ring on to the tray assembled.

6. If you are using the Natural Touch™ 360 bottles with weighted straw, please add the adapter, straw and weight (assembled) on to the tray as shown.

7. Put the lid on top and plug into outlet.

8. Switch on the unit, the unit will beep once.

9. Select sterilisation only function by pressing the button once. The buzzer will beep once and top light will come on. After 5 seconds the cycle will start automatically if there are no further button presses. Warm up should take approximately 3 minutes.

10. The sterilisation cycle will last approximately 5 minutes. The buzzer will beep once and the top light will switch off when the sterilisation cycle is complete. **WARNING:** Please wait 3 minutes before lifting the lid to allow the unit to cool down.

11. When cool, unplug and remove the lid carefully with the handle. LID WILL BE VERY HOT. Keep hands and face away from the unit when opening the lid. Now remove the tray.

12. Pour out any excess water and wipe dry.

WARNING: USING MORE WATER THAN SUGGESTED WILL INCREASE THE CYCLE TIME AND MAY EFFECT THE DRYING PERFORMANCE. USING LESS WATER MAY NOT STERILISE THE CONTENTS PROPERLY.

- STERILISING CHAMBER BECOMES HOT. APPROACH THE UNIT WITH CAUTION WHILE IN USE. LET IT STAND THREE MINUTES AFTER COMPLETION BEFORE ATTEMPTING TO OPEN.
- OPEN USING THE HANDLE ON TOP OF THE LID ONLY.
- POUR OUT EXCESS WATER AND UNPLUG APPLIANCE WHEN NOT IN USE, OR BEFORE CLEANING OR STORING.
- CLOSE SUPERVISION IS NECESSARY WHEN ANY APPLIANCE IS USED NEAR CHILDREN.
- USE PLASTIC BOTTLES APPROVED FOR BOILING OR GLASS HEAT-RESISTANT BOTTLES/CONTAINERS WITH THIS APPLIANCE.
- UNPLUG FROM OUTLET WHEN NOT IN USE AND BEFORE CLEANING.
- ALLOW TO COOL BEFORE PLACING OR REMOVING TRAYS AND BEFORE CLEANING.
- DO NOT OPERATE ANY APPLIANCE WITH A DAMAGED CORD OR PLUG AFTER THE APPLIANCE MALFUNCTIONS OR HAS BEEN DAMAGED IN ANY MANNER. RETURN APPLIANCE TO NUBY UK LLP FOR EXAMINATION, REPAIR OR ADJUSTMENT.
- ALWAYS USE UPPER AND LOWER TRAYS TO PREVENT DAMAGE TO BOTTLES.
- THE USE OF ACCESSORY ATTACHMENTS NOT RECOMMENDED BY THE APPLIANCE MANUFACTURER MAY CAUSE INJURIES.
- DO NOT PLACE ON OR NEAR A HOT GAS OR ELECTRIC BURNER, OR IN A HEATED OVEN.
- ALWAYS MAKE SURE UNIT IS "OFF" BEFORE REMOVING PLUG FROM WALL OUTLET.
- DO NOT USE APPLIANCE FOR OTHER THAN INTENDED USE.
- AFTER EACH USE, UNPLUG CORD FROM WALL OUTLET. DO NOT LEAVE CORD OR THE UNIT WITHIN CHILD'S REACH.
- CLEAN UNIT AND PARTS BEFORE INITIAL USE AND AFTER EACH SUBSEQUENT USE. WHEN IN USE, THE STERILISER CONTAINS BOILING WATER AND STEAM ESCAPES FROM THE VENTS IN THE LID. NEVER OPEN LID WHEN IN USE. **WARNING - FAILURE TO FOLLOW THESE INSTRUCTIONS MAY CAUSE SCALDING OR DAMAGE TO PRODUCT. SAVE THESE INSTRUCTIONS.**

Before using your Nuby™ Electric Steam Steriliser & Dryer for the first time

STERILISATION ONLY instructions:

Note: Items to be sterilised must be washed before they are put in the steriliser.

PLEASE RUN A FULL STERILISATION CYCLE

1. Pour 90ml into the base of the unit (onto the heater plate).
2. Place the body on top of the base. Place the bottle rack inside the unit, place the tray on top and put the lid on. Plug into outlet.
3. Switch on the unit, the unit will beep once.
4. Select sterilisation only function by pressing the button once. The buzzer will beep once and the top light will come on and flash. After 5 seconds, the cycle will start automatically if there are no further button presses. The warm up process takes approximately 3 minutes.
5. The sterilisation cycle will last approximately 5 minutes. The buzzer will beep three times and the top light will switch off when the sterilisation cycle is complete. **WARNING:** Please wait 3 minutes before lifting the lid to allow the unit to cool down.
6. When cool, unplug and remove the lid carefully with the handle. LID WILL BE VERY HOT. Keep hands and face away from the unit when opening the lid. Now remove the main body.
7. Pour out any excess water and wipe dry.
8. The steriliser is now ready for use.

PLEASE NOTE: EXCESS WATER SHOULD BE Poured OUT OF THE FRONT OF THE STEAM STERILISER AND DRYER TO PREVENT WATER ENTERING AIR VENTS.

As well as bottles you can sterilise breast feeding accessories and any other items that can be boiled. (please refer to the manufacturer's instructions regarding sterilisation)

1. Remove the lid, tray and bottle rack
2. Pour 90ml water into the base of the unit (directly onto the heater plate).
3. Replace the bottle rack and place washed bottles upside down (without teats) onto the locators with bottle hoods on top.
4. Place the tray on top of the main body.

Print Above pages front and back. Side B should be printed on the BACK of the same page that Side A is printed on

Once all pages are printed front and back, fold pages in center and assemble so that booklet pages will be read in consecutive order.
 Saddle stitch (staple) all pages together along foldline.

Bottle & Teat WARNING!

- Always use this product with adult supervision. Accidents have occurred when babies have been left alone with drinking equipment due to the baby falling or the product has become disassembled.
- Never use feeding teats as a soother.
- Continuous and prolonged sucking of fluids will cause decay. Tooth decay in young children can occur even when non-sweetened fluids are used. This can occur if the baby is allowed to use the bottle for long periods through the day and night, when saliva flow is reduced or if it is used as a soother.
- Always check food temperatures before feeding. Heating in a microwave oven may produce localised high temperatures.
- Take extra care when microwave heating.
- Always stir heated food to ensure heat distribution and test the temperature before serving.
- When making up a feed, follow the formula milk manufacturer's instructions and allow the freshly boiled water to cool before pouring it into the bottle.

CLEANING

- Before first use, clean the product.
- Clean before each use.
- Always wash the product immediately after use.
- Wash in warm soapy water and rinse in clean water or use a dishwasher.
- Do not clean with solvents or harsh chemicals.
- Do not allow product to come into contact with oil based foods (e.g. oil/tomato based sauces) as staining will occur.

- Before first use place the teat in boiling water for 5 minutes.
- Do not turn the teat inside out for cleaning. Damage could result. Use a teat brush.
- Suitable for all forms of sterilisation.

STORAGE & USE

- Inspect before each use and pull the teat in all directions. Throw away at first signs of damage or weakness.
- Do not store in direct sunlight or near a source of heat.
- Do not store with or allow to come into contact with solvents or harsh chemicals.
- Not suitable for use in a conventional oven or a combination microwave oven with the grill feature switched on.
- Keep all components not in use out of reach with children.
- Do not leave a feeding teat in direct sunlight or heat, or leave in disinfectant (sterilising solution) for more than recommended, as this may weaken the teat.
- For safety and hygiene reasons it is recommended that the feeding teat is replaced at least 2 months.
- Do not heat in a microwave with the bottle sealed. Remove the teat, locking ring and dome.
- Bottle and teat complies with EN14350

DUMMY

For your child's safety **WARNING!**

- Only use dedicated soother holders tested to EN12586.
- Never attach ribbons or cords to a soother, your child may be strangled by them.
- Inspect carefully before each use, especially when the child has teeth. Pull the soother in all directions. Throw away at first signs of damage or weakness.
- Do not leave a soother in direct sunlight or near a source of heat, or leave in disinfectant ("sterilising solution") for longer than recommended, as this may weaken the teat.

CLEANING & STERILISATION

- Before first use place the soother in boiling water for 5 minutes, allow to cool and squeeze out any trapped water from soother.
- This is to ensure hygiene.
- In the event that the soother becomes lodged in babies mouth, **DO NOT PANIC**, it can not be swallowed and is designed to cope with such an event. Remove from mouth with care, as gently as possible.
- Replace the soother after one month, for safety and hygiene reasons.
- Clean before each use. Wash in warm soapy water and rinse in clean water or use a dishwasher. Remove any water that may have entered the teat by squeezing the teat. Do not clean with solvents or harsh chemicals.
- Suitable for all forms of sterilisation.

- Do not store in direct sunlight or near a source of heat.
- Do not store or allow to come into contact with solvents or harsh chemicals.
- Never dip teat in sweet substances or medication, your child may get tooth decay.
- Always use this product under adult supervision.
- Soother Complies to EN1400.